

Access control

Since Version 1.3 a Networker web access must be authorized with username and password. Since version 1.4 the feature is include in the pro versions only.



Three different user accounts are differentiated:

- Administrator (Standard username: admin, Password: admin). This user is allowed to do everything (including user administration). This account **cannot** be deactivated.
- User (Standard username: user, Password: user). This user has read only access to the start page; blinking, restarting and shutting down Networker is also allowed. Also the GPIO page can be accessed, control of IOs is possible, but not the direction. This account can be deactivated by administrator.
- Guest (Standard username: guest, Password: guest) Guest has read only access to the start and GPIO pages. This account can be deactivated by administrator.



Do not forget to alter usernames and passwords in the user administration dialog!

Usernames and password can be up to 8 characters long.

Since version 1.4 pro the users are also used for the GPIO server.

From:
http://www.mobacon.de/dokuwiki/ - **MoBaCon**

Permanent link:
http://www.mobacon.de/dokuwiki/doku.php?id=en:netzer:accesscontrol&rev=1321276231

Last update: **2025/06/11 20:42**